FIXING ROLLER SHADE THAT DOES NOT ROLL UP EVENLY (TELESCOPING).

Not rolling up evenly is the most common problem with any type of roller shade. Telescoping is when the shade gathers to one side or the other as it is rolled up. This is typically a leveling problem, however; you do not have to remove the shade to fix it. Solution:

First check the mounting brackets to ensure that they are aligned and level. Ensure that the roller barrel is level.
 Please use a leveling device.

If the shade is leveled then there is one more thing you can do to prevent the shade from rolling up unevenly

Some fabrics have a tendency to telescope to one side or the other when being roller up. To remedy this, unroll
the shade until you can see where the fabric is attached to the roller. Place a small piece of masking tape at the
attachment on the opposite side end from where the shade is telescoping. A second or even third piece can be
placed on to fix more extreme telescoping problems.

